

All Events Rental

Frozen Drink Machine

How to use our frozen drink machine:

The machine will come with a 5-gallon cooler, mixing spoon, and pitcher for loading the mix into the machine.

Operating tips:

- If the red “low level” light comes on, immediately refill the hopper to prevent air from entering the freezing cylinder. If air does enter the cylinder (causing a gentle rocking motion) turn the machine off for a few minutes to allow the air to escape.
- At room temperature, the mix will take about 45 minutes to freeze. Pre-cooling the mix will reduce the freezing time.

Switch Positions:

1. Normal: Both switches in the snowflake position (right). The machine will freeze and stir the mix.
2. Cooling: Top switch in the snowflake position (right), bottom switch in the thermometer position (left). The freezer will automatically come on when necessary to keep the mix cooled to 40°F – used to pre-cool the mix or for overnight storage.
3. Cleaning: Top switch in the faucet position (left), bottom switch in the snowflake position (right). The machine will stir but will not freeze. (As shown.)
4. Off: Top switch in the hand position (middle), bottom switch in the snowflake position (right). The machine is completely off.



Setup:

1. Place the machine on a stable, level surface with at least 8” of clearance on all sides to prevent overheating.
2. Set the machine near a dedicated 20 amp grounded electrical source, so that you will not need an extension cord.

Instructions:

1. Pour two ½ gallon cartons of mix into the 5-gallon cooler. (One gallon of mix.)
2. Using the empty mix cartons, pour six ½ gallon cartons of water into the 5-gallon cooler. (Three gallons of water.)
3. If desired, add three quarts of alcohol to the 5-gallon cooler.
 - Any quantity of alcohol can be used, as long as it is less than 25% (one gallon) of the total mix.
4. Stir thoroughly with the mixing spoon.
5. Use the pitcher to load the hopper, taking care not to overfill (keep the mix about one inch from the top).
6. Plug the machine in and turn both switches to the snowflake position (right). Allow 45 minutes to freeze.
7. Dispense the drink by pulling the faucet knob straight out.

Cleaning:

1. Empty the mix using the faucet knob and turn the switches to the off position.
2. Fill the hopper with two gallons of clean water and wipe the hopper clean.
3. Turn the switches to the cleaning position and let the machine stir for 2 minutes.
4. Drain the machine using the faucet knob.
5. Repeat steps 2-3 until the water is clear.
6. Turn the switches to the off position.

