

All Events Rental

Tabletop Popcorn Machine

How to use our popcorn machine:

Operating tips:

- Only plug the popcorn machine into a grounded outlet of appropriate volts and amps.
- Avoid serious burns! Do not touch the kettle while it is hot!
- Do not cover the air vent holes on the side of the machine!

Setup:

1. Place the popcorn machine on a stable, level surface, such as a table or counter.
2. Make sure to set the popcorn machine near a grounded electrical source so that you will not have to use an extension cord.
3. There are three switches:
 - Light & Warmer Switch: Turns the heat lamp and warmer on to keep already popped corn warm.
 - Kettle Motor Switch: Turns the rotating kettle motor on – Required to pop corn!
 - Kettle Heat Switch: Turns the kettle heating element on – Required to pop corn!



Instructions:

1. Plug the popcorn machine in, flip the Kettle Motor Switch and Kettle Heat Switch to ON.
 - Before the first batch, allow the cold kettle to warm up for 2-3 minutes.
2. Cut the top off a Naks-Pak corn and oil package, raise the kettle lid, and squeeze the Naks-Pak into the kettle.
3. When popping has slowed to less than one every 10 seconds, rotate the handle to empty the kettle; return the kettle to the upright position.
4. Once the first batch has been popped, you may turn on the Light & Warmer Switch.
5. Repeat steps 1-3.
6. Turn off the Kettle Heat Switch on the final batch when the corn begins to pop. This will prevent smoking and burning.
7. Once the final batch has been dumped, turn off the Kettle Motor Switch.
8. Once you are done serving popcorn, turn off the Light & Warmer Switch.
9. At this point, all switches should be off.

Cleaning:

1. Allow the kettle to cool until just warm enough to handle; unplug the kettle and remove from the machine.
2. Wipe the kettle, kettle lids, crossbar, and exterior clean with a wet wash cloth.
 - Do not immerse the kettle in water!
3. Remove popped corn and pack in bags.
4. Remove the "old maid" pan, empty the kernels and wipe clean.
5. Wipe the interior of machine with a warm wash cloth, paying special attention to the windows.